

Nastavení snímače Zebex Z-3220 pro spolupráci s programem TRIFID



Start of Configuration



RESET



Send number as keypad data



Header



HT
(TAB)



Set



End of Configuration